

## Removing Electrode Motion Artifacts Using Butterworth Highpass filter

```
clc;
clear all;
close all;
%Loaded ECG Signal
load('100m.mat')
%Removing the Base and Gain from ECG Signal
ECGsignal_original = (val -1024)/100;
Fs = 360;
%Frequency of PowerLine Interference
L = length(ECGsignal_original);
t = (1:L)/Fs;
%Defining Cutoff Frequency and order
fc = 5;
n = 2;
[b,a] = butter(n,fc/(Fs/2),'high');
t1 = tf(b,a,1/Fs)
t1 =
 0.9402 \text{ z}^2 - 1.88 \text{ z} + 0.9402
    z^2 - 1.877 z + 0.8839
Sample time: 0.0027778 seconds
Discrete-time transfer function.
Model Properties
[z,p,k] = tf2zp(b,a)
z = 2 \times 1
    1
    1
p = 2 \times 1 complex
  0.9384 + 0.0581i
  0.9384 - 0.0581i
k = 0.9402
zplane(z,p,k)
grid on
```



w = 0:2\*pi/Fs:pi; freqz(b,a,w)



```
%Reconstructing the signal
ECG_filtered = filter(b,a,ECGsignal_original);
subplot(211)
plot(t,ECGsignal_original)
title('ECG Signal with Artifacts')
xlabel('time(s)')
ylabel('Amplitude(mV)')
xlim([0.00 2.23])
ylim([-11.18 -8.81])
grid on
subplot(212)
plot(t,ECG_filtered)
title('ECG Signal without Artifacts')
xlabel('time(s)')
ylabel('Amplitude(mV)')
xlim([0.00 2.16])
ylim([-2.0 5.0])
grid on
```

